



AIR PREPARATION UNITS

PRECISION REGULATOR Series PR

Cat No PR - 01 - 01

PRECISION REGULATOR - 1/4

Features

- Precise pressure control
- ☐ Characteristics such as flow characteristic, pressure characteristic and repeatability are superior compared with standard regulators.
- □ Excellent relief flow characteristic is available.
- □ Suitable for Panel & Modular mountings
- □ Diaphragm operated, relieving type (Exhaust)
- ☐ Clamp and pressure gauge can be mounted either in the front or the back
- □ Can be assembled with F13, FRC13, FS13 & L13 series of products



Applications

Some of the applications of precision regulator,

- 1. Manufacturers of air gauging equipment,
- 2. Medical equipments,
- 3. Leak testing equipment,
- 4. Polishing machinery,
- 5. Web tensioning,
- 6. Measuring machines,
- 7. Ink or paint, Robotics spraying systems,
- 8. Tank blanketing and many...

Technical Specification

Model	PR13611	PR13612	PR13613
Port size	G1/4		
Pressure gauge port size	G1/8		
Maximum supply pressure ¹ (bar)	10		
Minimum supply pressure (bar)	Set pressure +0.5		
Regulating pressure range (bar)	0.05 - 2	0.1 - 4	0.1 - 8
Sensitivity	Within 0.2% of full span ²		
Repeatability	Within ±0.5% of full span ²		
Air consumption (Its / min) ³	6		
Flow * (Its / min)	600	900	1100
Ambient / fluid temperature	5°-60°C		
Materials of construction	Aluminium, SS, Brass, Celcon, Steel, NBR		
Weight (Kg)	0.490		

^{*} Supply pressure - refer Flow graph

^{1 -} With the condition of no flow on the outlet side. The minimum differential pressure from setting pressure should be always +0.5 bar.

^{2 -} Full span - Maximum setting pressure of the product.

^{3 -} Supply pressure 10 bar. Air is being exhausted to the atmosphere.




AIR PREPARATION UNITS


PRECISION REGULATOR Series PR

Cat No PR - 01 - 01

Dimension



Accessories



How to order :- Mention the ordering number required Example :- Clamp - Ordering no : A2C05

Precautions

- 1. If the supply pressure line contains drainage or dirt, etc., the disc can become clogged leading to malfunction, and therefore, in addition to an air filter be sure to use a mist separator.
- 2. Never use a lubricator on the supply side of the regulator, as this will positively cause the disc to become clogged and lead to malfunction. If lubrication is required for terminal devices, connect a lubricator on the output side of the regulator.
- 3. Do not use a precision regulator outside the range of its specifications as this can cause failure. (Refer to technical specifications)
- 4. When mounting is performed, make connections while confirming port indications.
- 5. Air is normally released from the bleed hole (the hole on the side of the body's mid-section). This is necessary consumption of air based on the construction of the precision regulator, and is not an abnormality.
- 6. Make sure to tighten the lock nut after pressure adjustment.




AIR PREPARATION UNITS


PRECISION REGULATOR Series PR


Cat No PR - 01 - 01

Flow Graphs













Relief Characteristics









Pressure Characteristics



PR13612




PR13611



How to order







Pressure range		
1	0.05 to 2 bar	
2	0.1 to 4 bar	
3	0.1 to 8 har	

Ordering Example :- Precision Regulator - 1/4 size (with G1/4 port), with pressure range 0.1 - 8 bar: Ordering No: PR13613.